


Comfort Glow® LFP33PR

UNVENTED PROPANE/LP GAS FIREPLACE

ILLUSTRATED
PARTS
BREAKDOWN

REMOTE READY MODEL
LFP33PR



OWNER'S MANUAL

PARTS LIST

This list contains replaceable parts used in your fireplace. When ordering parts, follow the instructions listed under *Replacement Parts* on page 23 of this manual.

REMOTE READY MODEL LFP33PR

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	104937-01	Log #1, Middle	1
2	104938-01	Log #2, Back	1
3	104936-01	Log #3, Front	1
4	104939-01	Log #4, Crossover	1
5	103778-01	ODS Pilot (LP)	1
6	098249-01	ODS Nut	2
7	099387-03	Pilot Tube	1
8	104229-02	Burner Outlet Tube	1
9	102843-01	Burner Clip	1
10	099056-19	Burner Orifice Injector	1
11	102772-01	Burner	2
12	M11084-38	Screw, #8 x .38	2
13	104236-01CK	Painted Base Assy	1
14	M12461-26	Screw, #10 x .32	4
15	104238-01CK	Firebox Bottom	1
16	103284-03	Wiring Harness	1
17	098265-02	Elbow, Male	1
18	103782-01	Valve Bracket	1
19	103781-02	Gas Control Valve	1
20	098271-03	Ignitor Cable	1
21	102445-01	Piezo Ignitor	1
22	098304-01	Pan Head Screw #10	10
23	099998-01	Switch	1
24	104241-01	Remote Switch Bracket	1
25	103587-02CK	Switch Plate	1
26	097809-02	Male Connector	1
27	101628-03	Flexible Connector (Hose)	1
28	M50104-02	Bushing	1
29	M11084-26	Screw, #10 x .38	4
PARTS AVAILABLE — NOT SHOWN			
	100639-01	Caution Decal	1
	101416-43	Information Video	1